

POWERFLEX®

PART NUMBER

PFF5-801

DESCRIPTION

FRONT UPPER CONTROL ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- | | |
|----------------------------|---------------------------------|
| 4 x Polyurethane Bushes | 1 x PTFE/Silicone Grease |
| 2 x Stainless Steel Sleeve | 1 x Flat Cut Mild Steel Washers |
| 3 x Mild Steel Washers | |

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original arm from the car.
2. Press out the original bush including its outer shell.
3. Clean away any dirt and corrosion from the arm.
4. Apply a small amount of the supplied grease to the outside of the bush and press into the arm.
5. Apply more grease to the bore of the bush and press in the sleeve.
6. Refit arm to the car, placing the supplied washers on the outside of the bushes. NB, the flat-edged cut washer should fit the right-hand side chassis mounting point to clear the captive bracket.
7. Refit the arm and tension all hardware to the manufacturers recommended torque settings.

