

POWERFLEX®

PART NUMBER

PFF60-101/201

DESCRIPTION

FRONT LOWER WISHBONE BUSH

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane Bushes 4 x Outer Shells
4 x Stainless Steel Sleeves 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original wishbone bushes (x4) including outer shells. A dedicated removal tool may be used to ease the removal of the original bushes.
2. Clean the bore of any burrs or dirt to leave a clean, dry finish.
3. Press the outer shells into the holes in the wishbone. This must be done starting from the inside of the wishbone, pushing outwards.
4. Apply some of the supplied grease to the outside and bore of the bushes and push them into the outer shells.
5. Push the stainless steel sleeves inside the bore of the bushes.
6. Re-fit the wishbone back to the car and tension all hardware to manufacturers recommended torque settings.



Figure 1- Bush fitted in wishbone