

POWERFLEX®

PART NUMBER

PFR16-810

DESCRIPTION

REAR BEAM BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes 1 x PTFE/Silicone Grease
2 x Polyurethane B Bushes 2 x Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush and clean away any dirt and corrosion, whilst also filing away any sharp edges.
2. Insert Polyurethane Bush A into the arm, ensuring that it is inserted into the side of the arm that faces the outside of the car.
3. Insert Polyurethane Bush B into the other side of the arm, ensuring both sides sit flush within the arm's bore.
4. Apply some of the supplied grease to the outer surface of the Stainless Steel Sleeve, and insert it into the bore of the Polyurethane Bushes, ensuring it sits flush in the bore.
5. Reinstall the arm and tension all hardware to the manufacturer's torque settings.

