

POWERFLEX®

PART NUMBER

PFR5-425

DESCRIPTION

REAR DIFF FRONT MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane Bushes 1 x PTFE/Silicone Grease
2 x Stainless Steel Sleeves 2 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the original bushes from the subframe.
2. Fit the polyurethane bushes into the subframe.
3. Using the supplied grease apply to the bore of the bush and the outside of the stainless steel sleeve. Push the sleeve through the bush.
4. Place a washer on the larger diameter of the front bush, use the original bolt and tighten to the manufacturers recommended torque settings.

