



PART NUMBER
PFR69-514

DESCRIPTION
REAR SUBFRAME BUSH INSERTS

INSTALLATION GUIDE

Contents (parts per car):

4 x Upper Bushes
4 x Lower Bushes
1 x grease



*Please read the complete fitting instructions and check package components before fitment.
This installation guide is to be used in conjunction with workshop manual.*

It is recommended that:

- all work to be carried out by a licenced technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Installation Guide:

- Support the sub frame, undo the mounting bolts lowering the sub frame enough to insert the longer part in from the top of the original bush.
- Apply a small amount of grease to the insert, line up the holes as necessary and insert the bush.
- Insert the shorter lower insert from under neath again applying grease and aligning the holes as necessary.
- Make sure the upper washer is refitted and the lower plate is used again.
Tip: if the upper washer has tags, flatten them out for proper fitment
- Re fit sub frame and tighten up bolts to the manufactures settings.



Upper Washer

Lower Washer